



EN You can find safety information at www.ewent-online.com/safety
NL Kijk op www.ewent-online.com/safety voor de veiligheidsinformatie

EN For service, manuals, firmware or updates visit www.ewent-online.com
NL Voor service, handleidingen, firmware updates bezoekt u www.ewent-online.com

FR Vous pouvez trouver des informations portant sur la sécurité sur www.ewent-online.com/safety
IT È possibile trovare informazioni sulla sicurezza sul sito www.ewent-online.com/safety
ES Puede encontrar información de seguridad en www.ewent-online.com/safety
DE Sicherheitshinweise finden Sie unter www.ewent-online.com/safety
PT Pode encontrar informações relativas a segurança em www.ewent-online.com/safety
HU A biztonsági információkat a www.ewent-online.com/safety oldalon találhatja meg
CZ Bezpečnostní informace můžete nalézt na adrese www.ewent-online.com/safety
DK Du kan finde sikkerhedsoplysningerne på www.ewent-online.com/safety
NO Du finner sikkerhetsinformasjon på www.ewent-online.com/safety
SE Du hittar säkerhetsinformation på www.ewent-online.com/safety
FI Turvallisuustiedot löytyvät osoitteesta www.ewent-online.com/safety
BG Информация за безопасност ще откриете на www.ewent-online.com/safety
GR Μπορείτε να βρείτε πληροφορίες ασφαλείας στη διεύθυνση www.ewent-online.com/safety
TR Güvenlik bilgilerini www.ewent-online.com/safety adresinde bulabilirsiniz.

EN Made in China

NL Geproduceerd in China **FR** Fabriqué en Chine **IT** Prodotto in Cina **DE** Hergestellt in China **ES** Hecho en China **PT** Fabricado na China **HU** Kínában készült **CZ** Vyrobeno v Číně **DK** Fremstillet i Kina **NO** Laget i Kina **SE** Tillverkad i Kina **FI** Valmistettu Kiinassa **SI** Izdelano na Kitajskem **BG** Произведено в Китай **GR** Κατασκευασμένο στην Κίνα **PL** Wyprodukowano w Chinach.

5 Year Warranty Ewent, Koolhovenstraat 1E, 3772 MT Barneveld, The Netherlands

FR Pour l'entretien, les manuels, les mises à jour du firmware ou l'assistance, visitez www.ewent-online.com
IT Per servizi, manuali, aggiornamento firmware e supporto visitare www.ewent-online.com
ES Para obtener asistencia, manuales, actualizaciones de firmware o soporte, visite www.ewent-online.com
DE Dienstleistungen, Handbücher, Firmware-Updates oder Support-Dienste werden unter www.ewent-online.com angeboten
PT Para assistência, manuais, atualizações de firmware ou apoio técnico, visite www.ewent-online.com
HU Szerviz, kézikönyvek, firmware-frissítések és támogatás ügyében látogasson el a következő oldalra: www.ewent-online.com
BG За сервис, ръководства, актуализации на фърмуера или поддръжка посетете www.ewent-online.com.

EN For PLUGGABLE EQUIPMENT, the socket-outlet shall be installed near the equipment and shall be easily accessible
NL Zorg dat het stopcontact dichtbij en gemakkelijk bereikbaar is vanaf het apparaat

FR Une prise électrique facilement accessible est nécessaire près de l'appareil **IT** È richiesta una presa di corrente, e pertanto è raccomandabile che questa sia nelle immediate vicinanze e facilmente raggiungibile
DE Eine Steckdose wird benötigt, die in der Nähe und einfach vom Gerät aus zugänglich sein sollte
ES Se necesita una toma de corriente que debe estar cerca y de fácil acceso desde el dispositivo
HU Olyan konnektorra van szüksége, mely közel van és könnyen megközelíthető az eszköz számára
PT Uma tomada deve estar perto e facilmente acessível a partir é necessário o dispositivo
BG За оборудване, което се включва, контактът трябва да се намира в близост до оборудването и да е лесно достъпно.



For Windows		For Android		For iOS / Mac OS	
FN + Windows	Activate Window Functions	FN + ESC	Home	FN + iOS	Activate iOS / Mac Functions
FN + ESC	Homepage default web browser	FN + F1	Return	FN + ESC	Home
FN + F1	Help	FN + F2	E-mail	FN + F1	Brightness -
FN + F2	Mail	FN + F3	N/A	FN + F2	Brightness +
FN + F3	N/A	FN + F4	Music	FN + F3	Virtual Keyboard
FN + F4	Music Player	FN + F5	Search/Web	FN + F4	Screenshot Key
FN + F5	Search	FN + F6	N/A	FN + F5	Search
FN + F6	N/A	FN + F7	Previous Track	FN + F6	Language Switching
FN + F7	Previous Track	FN + F8	Play/Pause	FN + F7	Previous Track
FN + F8	Play/Pause	FN + F9	Next Track	FN + F8	Play/Pause
FN + F9	Next Track	FN + F10	Mute	FN + F9	Next Track
FN + F10	Mute	FN + F11	Volume -	FN + F10	Mute
FN + F11	Volume -	FN + F12	Volume +	FN + F11	Volume -
FN + F12	Volume +	DEL	Lock	FN + F12	Volume +
				DEL	Lock